

Maintenance Supplies

Operator's Manual - A comprehensive manual is shipped with each new tool. It includes a parts list and drawing, seal replacement, dis-assembly and assembly procedures, and troubleshooting. Most are in CD format so that you may print a copy whenever you wish. If you need a paper copy, remember to ask.

Service Kits - Everything needed for routine operation. This is a single service kit including high pressure seal, critical o-rings, a seat for the high pressure seal (in some cases), 6 oz. of viscous fluid for the rotation speed control governor (where applicable), fill tube or syringe needed to service the tool. Call for specific kit content.

Seal Kits - Identical to Service Kit, but excludes viscous fluid, fill tube, and syringe. For customers who already have these items.

Overhaul Kits - Everything that normally wears out. Includes a single high pressure seal and seat, shaft seals, bearings, 6 oz. viscous fluid (where applicable). Call for specific kit content.

Tool Kits - Different for every tool, special tools for seating shaft seals, adjustments, etc.

Lubricants - These are available in their manufacturers' packaging, for customers' convenience.

Tool Model	Service Kit	Seal Kit	Overhaul Kit	Tool Kit	Lubricant
Barracuda - BC-K - 20 Kpsi	BC 600	BC 602	BC 610	BC 612	GP 042
Barracuda - BC-UH - 40 Kpsi	BC 600-UH	BC 602-UH	BC 610-UH	Bc 612	GP 042
CyClean 3D	CY 600	CY 602	CY 610	CY 612	BJ 048-S
Hurricane 3D	HC 600	HC 602	HC 610	HC 612	BJ 048-S
BJV (Obsolete)	BJ 600-X	BJ 602	BJ 610-X	BJ 612	BJ 048-X
BJV-M	BJ 600-M-X	BJ 602-M	BJ 610-M-X	BJ 612	BJ 048-X
BJV-20K	BJK 600-X	BJK 602	BJK 610-X	BJK 612	BJ 048-X
RJV	RJ 600-X	RJ 602	RJ 610-X	RJ 612	BJ 048-X
RJV3 (Obsolete)	RJ 600-K	RJ 602-K	RJ 610-K	RJ 612	RJ 048-VF
Gopher - GO-M9 - 20 Kpsi	GO 600	GO 602	GO 610	GO 612	GP 044
Gopher - GO-H9 - 40 Kpsi	GO 600-UH	GO 602-UH	GO 610-UH	GO 612	GP 044
Badger	BA 600	BA 602	BA 610	BA 612	BJ 048-F
Marten	MT 600	MT 602	MT 610	MT 612	BJ 048-S
Ferret	FT 600	FT 602	FT 610	FT 612	BJ 048-S
Weasel	EZ 600	EZ 602	EZ 610	EZ 612	BJ 048-S
Warthog WS-1/2, WSH	WS 600	WS 602	WS 610	WS 612	BJ 048-F
Warthog WH-1/2 & 3/4	WH 600	WH 602	WH 610	WH 612	BJ 048-F
Warthog WG-1	WG 600	WG 602	WG 610	WG 612	BJ 048-F
BJV-H	BJ 600-H-X	BJ 602-H	BJ 610-H-X	BJ 612	BJ 048-X
CST	CST 600		CST 610		GP 048
SA 1900, 1909	HI 600		HI 610		GP 048
SA 2000, 2012	FS 600	FS 602	FS 610	FS 612	GP 048
SL-P8P4	SL 600-P		SL 610-P	SL 612	GP 048
SL-A9AV9	SL 600-K		SL 610-K	SL 612	GP 048
SG-P8P8 & SG-A12AV12	SG 600		SG 610	SG 612	GP 048
SG-P12P12-M & SG-A16A16	SG 600-M		SG 610-M	SG 612	GP 048
SG-CCN	SG 600-CCN		SG 610-CCN	SG 612	GP 048
SH-P8P8	SH 600		SH 610		GP 048
SM-P16	SM 600-P16		SM 610-P16	SM 612-P16	GP 048
SM-P20	SM 600-P20		SM 610-P20	SM 612-P20	GP 048
HI	HI 600		HI 610		GP 048
FS	FS 600	FS 602	FS 610	FS 612	GP 048
HF (Obsolete)	HF 600		HF 610		GP 048
HF-2D (Obsolete)	HF 600		HF 610		HF 042
OQ (Obsolete)	FS 600		OQ 610		GP 048

Note: "X" indicates "Fast" or "Slow" rotation speed range, please specify.